# Release Notes TwinCAT Tria-Link Library

#### Release 3.10.4.0:

Release Date: 2024-10-20

SVN Revision: 1486

#### **Changes:**

new: DirectFeed: New interpolator introduced for position and current

#### Release 3.10.3.0:

Release Date: 2024-10-24

SVN Revision: 1478

#### **Changes:**

new: motion command halt (TL\_MC\_Halt), minimum firmware 4.23

fix: gantry homing returned a false error

fix: bound check added for TL\_Axis2

fix: bound check added for TL\_MC\_MoveSynchronized(2)

#### Release 3.10.2.0:

Release Date: 2024-03-05

SVN Revision: 1403

#### **Changes:**

fix: Check axis index range (DirectFeed)

fix: prevent division by zero for TL\_AboSubscriberMaster/TL\_AboSubscriberMaster5

## 3.10.1: (SVN1359) bugfix 0

new: function block for position settling analysis (TL\_PositionSettlingAnalysis)

fix: leave of transition states added for coupling mode (MoveSynchronized)

## 3.10.0: (SVN1340) bugfix 3

chg: input variable name TL\_AxisO.referencePosition changed to

TL\_Axis0.referencePos due to a significant function change in drive controlled homing (gear\_factor now taken into account)

fix: the division by zero caused by gear factor equal zero, caught with a new error message

new: error message if hardware id of trialink adapter is unknown

fix: wrong initialization for legacy drives (slow publish)

fix: time behavior optimized during coupling

fix: actual position was not updated in simulation mode

## 3.9.4: (SVN1326) bugfix 0

fix: prevent invalid fast publish axis data during trialink startup (first time boot)

fix: Omit reset of foreign subscribtions at trialink boot

## 3.9.3: (SVN1314) bugfix 0

fix: If the AboSubscriber received no abos, there was no interpolation: Caused a wrong actual position update

new: actual velocity output variable added (act\_vel) for TL\_Axis2 and TL\_AxisSlow chg: set act\_vel and act\_err to zero if simulation is on

## 3.9.2: (SVN1312) bugfix 3

chg: The smooth interpolator is now selected by default

fix: Direct feed issues in DMA situations

chg: Minimum firmware release for the TL/1 is now 1.10.63

fix: rebooting Trialink without prior Trialink.Execute:=FALSE could cause RegisterWrite address problems

chg: The error 070 now also reports if Trialink.callFast is not faster than callSlow (fix1)

fix: Clear the message string if the messageId changes

fix: check acceleration feed forward only if OfflineFeedForward is active. (fix2)

fix: Support TL\_Trialink for legacy axes: (MC\_axis.intern.messageLegacy was
not set True within TL\_AxisSlow) (fix2)

chg: With new interpolater setpoint filter can be switched off (fix3)

new: Separate the messages descriptions for TwinCAT Trialink from TwinCAT EtherCAT (fix3)

fix: Register offset for Ffx, Ffv, Ffa corrected (fix3)

fix: Condition for float40 register read fixed (fix3)

#### 3.9.1: (SVN1232) bugfix 0

new: Smooth interpolator TL\_Axis2::intern.interpolator1.mode
=Interpol5\_SMOOTH\_XXXXXXXX

#### 3.9.0: (SVN1228) bugfix 3

new: First official release for the TL/Rev1 PCIe board including DMA, see SCN010 for braking changes

new: TL\_Trialink2 now sends XVA tripplets by default, see

Trialink.pll.enforceXVAtripplets

new: error 79 for an adapter without driver

chg: Trialink.Config.FastFilterFrequency is now also the corner frequency for XVA-

based interpolation using TL\_Trialink2

new: Twincat events default settings do not throw events anymore

chg: TL Axis2::messageId for axis messages instead of from errorId

chg: The TAM System Explorer can detach a TwinCAT Axis similar to EtherCAT

## 3.8.2: (SVN1201) bugfix 5

new: Support Trialink.Config.DmaDisable parameter instead of

Trialink.Trialink.Pci.DmaEnable

fix: Initialize fifos to account for dma restart, turn off tx DMAs for TL/1 FW 0x8CB

fix: DirectFeed: Current calculation for offline feed forward (fix2)

fix: Fixed division by gear\_factor of the feed forward current and one sample shift corrected (fix3)

new: TL\_Trialink2 now sends XVA tripplets by default, see

Trialink.pll.enforceXVAtripplets (fix4)

fix: TL\_Axis2 objects in simulated mode must not try to access errorCounters
(fix5)

## 3.8.1: (SVN1178) bugfix 17

chg: Improove the axisPathInterpolator and use mode Interpol4\_MAV\_XXXXX as default setting (fixes 3 and 5)

new: Axis State Disabling

chg: MaximumStoppingTimeBeforeBrake and BrakeTimeBeforeDisable are not deprecated anymore but default set to zero

fix: actual position interpolators were not always updated (fix 4)

fix: polynomial coefficients are transmitted based on a scale of 100 us, not as

XVA (fix 9)

fix: MaximumBrakingTime = 0 must not skip stop for legacy drives (fix 10)

```
new: In simulation mode of TL_Trialink act_pos = commanded position (fix 10) fix: Allow ResetError in enabled state (fix 12) fix: In simulation mode, we should not propagate errors (fix 13, without SVN 1170) fix: Revert axisPathInterpolator default mode back to Interpol4_XXXXXX (fix 14) fix: Wrong interpolation timebase for TL_Trialink (fix14) and wrong rounding in tbl.ResamplingSteps (fix 15) fix: Streaming mode interpolator (fix 17)
```

#### 3.8.0: (SVN1127) bugfix 18

```
new: Support TLO400 adapters in adapter mode TL_Trialink2 with DMA and fast
publish for act_pos, act_err and digitalInputBits
new: TL_Axis2::digitalInputBits: Use Enum DigitalInputBits as a mask
chg: (!) Obsolete MaximumStoppingTimeBeforeBrakeDepreciated and
BrakeTimeBeforeDisableDepreciated
chg: Default Homing-Type is DriveControlled
chg: Remove loopback action during boot
new: Minimum FW Release Adapter 1041 -> 1302 (because of bug in adapter FW 1301)
chg: reduce TL_CH_AX_MAX from 32 to 16
new: Trialink.linkErrorCounter shows sum of all drive CRC counters
     TL_Axis2::TL_MC_AXIS_REF.linkErrorCounters.errorCountLink1/2 shows error
details
fix: publishMaster2Slave must wait for valid register from axis boot before
starting
fix: publishMaster2Slave must be disabled with last generation drives (fix 14)
fix: Prevent calling publishSlave2Master callFast until the slow task finished
(fix 14)
fix: The actual position must be calculated with the dedicated function in the
fast task (fix 14)
chg: CNC: Sercos Interface Stub, which is required, if an axis is removed and
added again (fix 14)
chg: CNC: MAIN_FAST to GEO Task (fix 14)
chg: CNC: Station Address starts with 10 (fix 14)
fix: wrong data type for actual position in DMA mode for new gen drives (fix 16)
fix: No tracking in simulation mode (fix 16)
fix: Remove DMA for Timestamp. Leave DMA for rest (fix 17)
fix: Gear factor was not used for actual position in DMA mode (fix 18)
```

## 3.7.5: (SVN1096)

```
new: Direct feed is now also supported with stream mode (TL_DirectFeedResempling2 has to be used)

chg: With TSD firmware >= 4.3 position latch is executed on drive for digital inputs with sampling rate of 10kHz

chg: Digital inputs renamed from AuxIn1..6 to DigIn1...Dig6 to be consistent with hardware manual
```

```
fix: Direct feed: Check is now done just for direct feed axes (bugfix1)
fix: Position latch: version check corrected (bugfix 2)
fix: Direct feed: df-stream does now also support simulated axes (bugfix 2)
fix: Position latch: version check corrected (bugfix 3)
fix: Avoid int32 over-run in timestamp wrap situations with
Trialink.Config.FastBufferTicks*FAST-Cycle > 2.5 ms (bugfix 4)
chg: Wait one tick after diagnostic stop before stop logging
new: New axis errors up to 316 AxisCommandError
fix: Include TL_AboSubscriberMaster5 again (bugfix 6)
fix: Extended TL_GetCommutationPosition for register2 (bugfix 7)
fix: TL_MC_RegisterRead type mask was not evaluated correcly (bugfix 7)
fix: Switch off command removed as this could interrupt the enabling
sequence(bugfix 8)
fix: RL_MC_Brake and TL_BrakeConfigGet updated for TSD80(bugfix 9)
fix: Switch off axes in case of old drives to avoid STO error - see also bugfix 8
(bugfix 10)
fix: The check for second master in the ring should only be done once to prevent
misleading error 069 (bugfix 11)
fix: Error 317 is set in case PLC is trapped in disabling state (bugfix 12).
new: DPRAM addresses (* 1300 *) (* 1304 *) (bugfix 12).
chg: Default ResetAdapterOnBoot is now FALSE, was TRUE but disabled completely in
Function block (bugfix 12).
fix: init of MC_MoveSynchronized::Asettings was not done on restart (bugfix 12).
fix: Withdraw of error 317 and return to run mode in this case. Log signals added.
(bugfix 13)
    fix: If STO started in Disabled state, it sometimes showed STO-Error instead
of STO-Warning due to a drive state transition issue
fix: Add debug code to MoveAbsolute (bugfix 15)
```

#### 3.7.4: (SVN1008)

```
new: Broadcast globaltime every 5 seconds (bugfix 3)
chg: MoveSynchronized2 issues a stop if execute is set to FALSE
    This way we can stop streaming without a drive StreamLossError
chg: Actual position is commanded position in simulation mode
chg: use method ActualPositionFast(Trialink:=Trialink) to get interpolated
positions in the fast task
```

## 3.7.3: (SVN996)

```
new: Report file generation "triamec-report-2018.txt" on start of
TaskExceedCompensation
chg: default Trialink.Config.FastBufferTicks := 7
fix: reference move caused stream loss error as data stream stoped before coupling
was released (bugfix 1)
```

#### 3.7.2: (SVN982) requires FW>2083 for TSD-drives

new: Signals. Homing. State and Distance, old Homing state

Signals.General.HomingState removed

chg: removed Config. Encoder, use drive config

Parameters.PositionController.MasterPositionSource instead (FW>2082)

chg: For TSD-drives we show the actual velocity instead of the commanded velocity

in the state telegram

chg: Changes to allow homing with option module implemented.

new: Fast stop implemented

fix: RDEeDRVERR\_PowerLinesNotOk is interpreted as warning if

RDSeDRVST\_NotReadyToSwitchOn

#### 3.7.1: (SVN913)

new: Optimized bus access if using TL\_Trialink2 and TL\_Axis2 instead of

TL\_Trialink, TL\_AxisSlow, TL\_AxisFast (FW>=5050 (TS) 2097 (TSD))

Trialink.Config.FastFilterFrequency is the corner frequency of the commanded position filter

new: Additional input Trialink.Diagnostics.aux allows logging external input data

fix: replace constants enabled (bugfix 8)

## 3.7.0: (SVN891)

!! breaking: This library requires FW>2087 on TSD devices due to the extended homing state feature

new: TL\_RegisterRead allows accessing 4 registers at once but has no Reg12\_40 and

 ${\tt Reg4\_DWORD\ outputs\ anymore}$ 

fix: TL\_PositionLatchReg2 can now latch DigInputs, but with bad timing accuracy
(SLOW TASK)

new: TL\_MC\_HOME supports drive controlled homing for TSD drives (FW>2087)

chg: The register layout was modified to account for new positionlatch features

new: Extended state in cyclic abo used for homing state

## 3.6.0: (SVN865+)

chg: Optimization of FIFO tail access saves system load!

new: register entries for identification, positionUnit, masterPosition, analogOut

chg: breaking register changes:

OptionModule.FirmwareId renamed to FirmwareRel

TOU1[0] renamed to AnalogIn

chg: Modifications to avoid warnings with compiler newer equal 3.1.40.20

chg: DirectFeed: Intreface modified.

chg: DirectFeed: Test added to check if velocity and acceleration are within the limits.

chg: DirectFeed: Events for error publication added.

chg: DirectFeed: Check if table position at the end of the table matches the

commanded cnc position.

fix: DirectFeed: Modulo calculation for position check fixed.

#### 3.5.0: (SVN799+)

new: Function blocks for direct feed re-sampling added chg: Modifications used for direct feed re-sampling added

# 3.4.1: (SVN782+)

new: Reference on adjacent EncoderIndex for TSxxx drives (special application) use ConfigurationManager settings:

ReferenceMethod := TL\_Config.ReferenceMethod.Marker

ReferenceFirstMask := 512; // instead of TL\_Config.ReferenceFirstInput.ExtIoA

#### 3.4.0: (SVN774)

new: Support 24V digitalInput for homing of TSD-drives (same as for old drives) (latching not in drive, but in Twincat)

chg: new entry Config.Encoder replaces TL\_MC\_Power.EncoderIndexForActPosition

chg: Support for FW2077, which does no longer support old register style

chg: BrakeTimeBeforeDisable is discarded with newer drives (TSD)

because brake time parameter is a config register parameter with newer drives

## 3.3.0: (SVN745)

chg: remove debug signal TL\_MC\_AXIS::rx\_test and corresponding

TL\_MC\_Power::pub\_aux

chg: no set position zero during boot. These changes do only apply for TSD-Series drives

chg: Register uses URI-offsets now and is not compatible for TSD80 FW < 2071 URI take more than 20 bits: extend internal register offset range to 22 bits

chg: rename General.Parameters.DriveName to General.Parameters.DeviceName

eng. Fendine deneralit arameter 3.51 Evename to deneralit arameter 3.52 Evename

 ${\tt new: support \ for \ absolute \ endat \ with \ TSD80 \ EncoderPersistency, \ ReferenceDone,}$ 

Digital Encoder Signals

new: RCTtCommutationCommands2, Encoder Velocity

#### 3.2.1: (SVN730)(TC2 SVN678)

chg: homing is now also supported for TSD80 chg: general enhancement of TSD80 support

fix: if axes are coupled, homig did not work in some cases

#### 3.2.0: (SVN713)(TC2 SVN678)

new: support for new current controller features of FW2071 of TSD80

chg: Changes of the drive register layout! Incompatible to earlier FW of the

TSD80!

## 3.1.0 (SVN704, Lib310.0, TC3 only)

new: allow receiving five (single) values per abo

new: TSD80 support: add register layout 19 MC\_AXIS.register2 and support for

doubles

## 3.0.5: (SVN692, Lib 305.4)

new: ReferenceType Tama, see AN108

fix: Check for Session handler garbage collector limit, fixed

chg: PLL correction time was 2.5\*fastTaskTime, now it is constant 25ms.

chg: Diagnostic files show position error instead of actual position: Err is not

interpolated, act can be seen from cmd in tracking situation(BugFix 4)

chg: Diagnostics: adaptations for Explorer scope

chg: reorganize error and event priorities

chg: avoid double read of publisher abos

fix: wrong type of PositionController.ControlOutputCurrentQ

new: Object TL\_AboSubscriberMaster5 receives 5 single float values

Object TL\_AboSubscriberMaster receives 1 Float40 and 3 single float values (old)

new: add missing commit option for Axis Environment

chg: message 075 not trialink "down", but short "shutting down"

chg: disable of moving axis first tries an emergency stop

ifMaximumStoppingTimeBeforeBrake<>0

chg: pll: adjust with sample time, different windows for boot and error179

chg: remove obsolete events: 131, 136, 138, 139, 141, 144

new: couple warning/error: sync 178/179 on pll sync problems

new: task exceeds compensation

## 3.0 (SVN639, Lib302.0)

chg: Compatibility changes for TwinCat3... The following are breaking changes: variable "method" in homing parameter not allowed in TC3 -> ReferenceMethod all axis parameters are now set in TL\_AxisSlow.Config move Trialink.FastHandler.pll.BufferTicks to Trialink.Config.FastBufferTicks move TL\_AxisSlow.MC\_axis\_Home.Position to TL\_AxisSlow.referencePosition chg: Error 069 has now a smaller priority than 070. New events 178/179 new: Diagnostic logfile generated on axis errors set path in Trialink.Config.RootFolder an empty path or Trialink.Config.DiagnosticMode is used to disable the feature the number of files in this folder is limited to Trialink.Config.DiagnosticNumberOfFiles chg: move library version to Diagnostics new: Add errors for STO firmware 1040, no parallel errors 130+260, changed event file new: Trialink.Config.TcEventShowReferenceInfos FALSE disables homingmove information messages new: Trialink.Config.TcEventShowWarnings FALSE disables all warningmessages new: 4th order interpolator for commanded positions accounts for highdynamic trajectories new: TL publishSlave2Master for ts<>ts Fast or ts/0.1ms<>n new: TL\_MC\_MoveAbsolute can now react in MAIN\_FAST, see AN108 chg: sample codes: new TL\_CNC and TL\_CNC\_AX with task exceed compensation capability

#### 2.2 (SVN553, Lib226)

new: Preparation FOR DMA with rx-iso, rx-asy, AND tx-sdram
new: Disable axis errors if Trialink down. STO errors may be configuredin
Trialink.Config
new: High resolution actual position
new: More registers for tama and position control parameters
chg: TL\_AboSubscriberMaster flexible interpolation and modulocapability on src1
chg: MoveAbsolute and MoveVelocity now signal 152=CommandAborted if anaxis error
 stops the move before reaching the final state (standstill or
ContinuousMotion)
new: Trialink events "Booting" and "Timeout"
chg: tiob: remove unused tRefTick, replace TL\_TiobFast byTL\_AboSubscriberMaster;
chg: publish: new fifo and SingleInterpolator for TL\_AboSubscriberMaster
new: each axis has its own event source for simultaneous display
new: Homing: add search info and show them in the event-display

## 2.1 (SVN502, Lib219)

chg: bug fix Float40 of lib chg: rename FPGA localbus device DEVencoder\_in\_out to DEVencoder\_DigIn chg: faster pll initialization new: Position-latch feature for digital IOs chg: recover MC\_Power on communication down (\*) chg: default direction of moveAbsolute is now shortestway (importantfor modulo axes) new: timeout error if boot not successful for 20 seconds chg: improve detection of two masters in the loop new: readyToOperate output of axis module (bridge voltage and STOdetection) new: distinguish errors and warning for STO and bridge voltage fix: message events block fixed new error problem new: independent TwinCat errors for axis and (power/homing) chg: prios of errorId of TL\_AxisSlow (1. axis error or warning 2. homing error 3. power error) fix: dualport ram sync problem on rx\_iso fifo and sync warning fix: TL\_publishSlave2Master bug chg: always set axis position to zero on ring boot

#### 2.0 (SVN476, Lib216)

new : major release with changes listed in AN160 (TL\_Trialink,

TL\_publishSlave2Slave, Homing)

new : Support STO

new : AN122 for CNC-Error 70091 in Manual und Auto Mode

fix : 12 hour bug

chg : turn off pwm if MC\_Power.enable=FALSE

## 1.8 (SVN 393, LIB 177)

fix : Endat 2.1 for more than 32 bits

change: nci-sample code with same structure as cnc

# 1.7 (SVN 383, LIB 176)

fix : moveSync does "shortest move" for proper init of Modulo axes

fix : Homing Setposition bug.

new : SetPosition zero during communication startup

new : generalized register access

change: new homing sequence statemachine

change: rename EnableManager to AxisGroup1 and make global

change: Triamec is now global

change: HMI based on Visual Expres 2010

new : smart sync to avoid PLL not locked errors
change: Endat 2.1: Improve error reporting and retry

#### 1.6 (SVN279, LIB 1.6.7)

support new AxisErrors, Endat, modulo spindle, improve interpolator direct sync in fasthandler, no sync task required anymore cleanup CNC parameters change: replace cnc FB "TL\_AxisPath" by lib FB "TL\_AxisFast" but without IN/OUT components. This allows using a coordinate trafo change: replace cnc FB "TL\_AxisModule" by lib "TL\_AxisSlow" change: ReferenceEnable instead of ReferenceStart

This allows controlled resetting of all axes homing flags note: encoder was removed because auto-calib is default > FW1030 to use fast encoder or Endat 2.1 see Application Notes.

## 1.4 (SVN 204)

changed homing behaviour: Clear Homing by Execute:=FALSE support stopping by an external event (e.g., endswitch-tama) support brake feature

## 1.3 Changes to the Beckhoff Sample Code of the HMI:

simplify T-access, see HLI\_DoChannelTFunction
moved CNCSystem.T\_cmd to CNCSystem.Channel[nChan].T\_cmd
moved PLC\_PRG/HLI\_SetAxisTrackingOperation and HLI\_SetAxisFeedHold to
TL\_CNC\_Status

We removed the following commands in the PLC\_PRG
- HLI\_SetAxisTrackingOperation in PLC\_PRG
- HLI\_SetAxisFeedHold
because these are already written in TL\_CNC\_FromPlc

also be aware, that
- PLCAxisEnable is the global variable of the GUI for enable.